## **Important Information**

	<ul> <li>Follow all instructions in the SMART Hub PE260 Configuration Guide to configure your SMART Hub.</li> <li>Connect all projectors and other display devices to your SMART Hub before configuring it. Use the connector screws to securely connect the video cables to the SMART Hub. Do not disconnect any display devices while the SMART Hub is in Configuration mode.</li> <li>If the main display stops working during configuration, press CTRL+ALT+F1. If the main display does not resume working, do the following:</li> <li>1. If you haven't done so already, connect a keyboard to the SMART Hub.</li> </ul>
	<ol> <li>Press and hold down the <b>Power</b> button on the SMART Hub to turn off the unit.</li> </ol>
	3. Wait 30 seconds, and then press the <b>Power</b> button on the SMART Hub to turn on the unit.
	<ol> <li>Press F8 on the keyboard once every one or two seconds until you see a menu of bootup options.</li> </ol>
	5. Select Last Known Good Configuration.