


Quick reference


SMART Audio™ classroom amplification system

Model CAS-340

Control unit top view



Control unit bottom view



1017155 Rev 02


Extraordinary made simple®

SMART

Microphone

Microphone input

3.5 mm jack for optional external microphone input.



To turn on the microphone


Press any button for one second.

To turn off the microphone

Press the mute button for four seconds.

Auxiliary input

3.5 mm jack for MP3 player or other audio source.



Soft button

Press to mute auxiliary audio input at the control unit. Refer to the user's guide (smarttech.com/kb/155322) for customization instructions.

Volume up


Press to increase the microphone volume.

Mute / Power off

Press to mute the microphone.
Press for four seconds to turn off the microphone.

Volume down

Press to decrease the microphone volume.



Status light

- Green (solid) - On
- Green (flashing) - Muted
- Red (solid) - Low battery
- Red (flashing) - Charging
- Amber - Programming

To customize the microphone

Press the soft button and the volume down button for five seconds. Refer to the user's guide (smarttech.com/kb/155322) for more information.

To adjust auxiliary input volume

Press the mute button, and then press the volume buttons to adjust volume for auxiliary audio inputs connected to the control unit.

To charge the microphone

Place the microphone facing forward in the microphone charging cradle after each use.

