


# SMART Board® 7000

Need some help with your display?  
Check out these basic troubleshooting tips.



## Turn on the display


Press the Power button on the convenience panel:



OR

Pick up a pen or the eraser.


**Important:** Return pens to their holders when you're done to recharge them. The color of the pens' lights indicates their status.



## Show the connected computer's desktop

After connecting a computer, tap the Home button below the screen:



Tap **Input** , and then tap the computer's thumbnail:



**Note:** Be sure to enable touch control of your computer by connecting a USB cable from the computer to the appropriate USB-B receptacle on the display.

## Use the iQ features

The display includes iQ features that you can use without connecting a computer. To access these features, tap the Home button below the screen:



You can then use all the iQ features described in the SMART Board display teacher guide ([smarttech.com/displayteacherguide](http://smarttech.com/displayteacherguide)).

