

Release notes

iQ system software 3.5

Overview

You can download the iQ system software from smarttech.com/downloads.

NOTE

The features available vary depending on the model of iQ appliance that's installed in your display. For more information, see the [Identifying your iQ appliance model wizard](#).

iQ system software 3.5.9042

Highlights

Release date	April 8, 2020
Software versions	iQ appliance (AM30): 3.5.9042

New features

System software	<ul style="list-style-type: none">Downloaded files can be saved in the Files Library.If the appropriate app is installed, the display can open a file.Added Czech, Danish, Dutch, English (UK), Estonian, Finnish, Greek, Hungarian, Latvian, Lithuanian, Polish, Romanian, Slovak, Slovenian, Turkish, and Welsh language support.
Screen Share	<ul style="list-style-type: none">SMART Screen Share app for iOS and Android devices can connect to the display using a QR code on the display's screen.Windows and Mac computers can be controlled using the SMART Screen Share app.

IMPORTANT

You can use SMART Screen Share app's touchback feature to control a computer that's connected to the display using the Screen Share app. For example, use touchback when presenting a PowerPoint file. Touchback doesn't replace connecting a computer to the display with video and USB cables.

SMART Notebook Player for the display (education models only)	<ul style="list-style-type: none">Ready-made activities are available to add to a page.You can search for videos using Bing.
Browser	Browser can download and save files in the Files Library

Resolved issues

System software	<ul style="list-style-type: none">• Selecting and deleting all files didn't delete all files [76661].• Scrolling through the library might have been slow if the Files Library contained too many files [49660].• When changing the display's wallpaper in Settings, browsing for images on a USB drive that contained hundreds of images was very slow [47834].• After locking down the Settings app remotely or disabling apps, some tabs in Settings remained visible [41045].
Screen Share	<ul style="list-style-type: none">• When an iOS device was streaming video and audio and then disconnected from the display by tapping X on the display, the audio continued [61366].• Laptops couldn't share the screen using Miracast [61204].• When writing or drawing on an annotation layer, you couldn't change the second pen's color while the first pen was writing [46979].• Users might have been prompted a number of times for a PIN when installing a certificate for networks and proxies [46465].• Text appeared blurry when using Google Cast in the Chrome browser or Cast from a Chromebook or mobile device [10784].
SMART Notebook Player for the display (education models only)	<ul style="list-style-type: none">• If more space was added to a page, the page contents might have become unreadable when the SMART Notebook file was exported as a PDF [64383].• If you opened a PDF file from a USB drive, notes you made were not saved to the PDF file when the USB drive was removed [55473].• If you exit a lesson without tapping the Stop button, the lesson might have reappeared if you started and then stopped a Shout It Out! activity [48441].• When presenting a SMART Notebook file on the display, the ink in the SMART Notebook file might not have been saved if the mobile device was no longer connected to a network [43205].• After you'd shared a SMART Notebook file from Class Panel or connected to Player on the display with Player mobile app, changes made to the SMART Notebook file weren't saved [40152].
kapp Whiteboard	After erasing everything and adding new ink to a Whiteboard, a pinned Whiteboard tile showed the default icon instead of a thumbnail [46676].

Known issues

System software	When copying a file that currently has the same file name as a file on a USB drive, the old file is not replaced on the USB drive. Rename the file on the display and then copy it to the USB drive [85347].
-----------------	--

Screen Share

- The Screen Share app on iPad with iOS 12.4.5 causes out-of-synch audio or no audio. Upgrade the iPad's operating system to the latest iOS version [90086].
- Screen Share closes unexpectedly when devices are using Miracast [386862, 386874, 399983].
- When Apple devices are connected to the display Screen Share closes unexpectedly when the second device to connect stops sharing its screen [35285].
- Miracast may experience stuttering in a congested network environment [35167].
- When an iOS device is disconnected from the display by tapping **X** on the display, the iOS device can't connect again [34683].
- After an unsuccessful attempt to share a device's screen using Miracast, the display's screen is black [34681].
- When streaming media with iOS devices using AirPlay, audio and video can become unsynchronized [34678].
- You may have trouble seeing the display from your AirPlay or Google Cast device. Tap **Reset** in the device lobby [33262, 33265, 33292].
- Screen Share can occasionally stop displaying content from a mobile device without disconnecting the mobile device [386094].
- Samsung mobile devices should use the Google™ Home app to share content [417994].
- Text may appear blurry when using Google Cast in the Chrome browser or Cast from a Chromebook or a mobile device [407403].
- Chromebooks that can't use h.264 cannot share their screen reliably [389774].

SMART Notebook Player for the display (education models only)

- The following SMART Notebook file content is not supported by SMART Notebook Player:
 - Flash® widgets
 - HTML5 widgets
 - GeoGebra
 - Lesson Activity toolkit
 - 3D objects
 - SMART blocks
 - Concept mapping
- The Player app closes unexpectedly when you open a SMART Notebook file that contains SMART response® 2 question set that has more than 10 images in it [18287].

Browser

Invalid SSL certificate message appears when accessing certain sites that uses a newer GlobalSign ECC Root CA

iQ system software 3.5.9042

Highlights


Release date

March 13, 2020

Software versions

- iQ appliance (AM40): 3.5.9042
- iQ appliance (AM50): 3.5.9042

New features

System software	<ul style="list-style-type: none">Downloaded files can be saved in the Files Library.If the appropriate app is installed, the display can open a file.SMART's app store is available and includes teacher guides, Google apps, and Microsoft apps.Added Czech, Danish, Dutch, English (UK), Estonian, Finnish, Greek, Hungarian, Latvian, Lithuanian, Polish, Romanian, Slovak, Slovenian, Turkish, and Welsh language support.
Screen Share	<ul style="list-style-type: none">SMART Screen Share app for iOS and Android devices can connect to the display using a QR code on the display's screen.Windows and Mac computers can be controlled using the SMART Screen Share app. <div> IMPORTANT You can use SMART Screen Share app's touchback feature to control a computer that's connected to the display using the Screen Share app. For example, use touchback when presenting a PowerPoint file. Touchback doesn't replace connecting a computer to the display with video and USB cables.</div>
SMART Notebook Player for the display (education models only)	<ul style="list-style-type: none">Ready-made activities are available to add to a page.You can search for videos using Bing.
Browser	Browser can download and save files in the Files Library

Resolved issues

System software	<ul style="list-style-type: none">User couldn't sign in if a PIN or password was set up when installing network certificates [85707].Selecting and deleting all files didn't delete all files [76661].When a user was signed in, the display couldn't install a network certificate to authenticate devices connected to a wireless network [68438, 68439].Disabling the Library for the kapp Whiteboard disabled the Library for all signed-in users. All kapp Whiteboards would eventually be deleted too [67803].When writing or drawing on an annotation layer, you couldn't change the second pen's color while the first pen was writing [46979].After locking down the Settings app remotely or disabling apps, some tabs in Settings remained visible [41045].
-----------------	---

Screen Share	<ul style="list-style-type: none">• The display showed a black screen when sharing from an Apple TV [80626].• Audio was missing when using the SMART Screen Share app on a Mac computer with macOS 10.15 [80446].• The display might not have automatically disconnected from the Wi-Fi network when a device using Miracast shared its screen [66324].• When both Ethernet and Wi-Fi were enabled on the display, the Screen Share app showed the connection information for the Wi-Fi connection [60444].• Devices that couldn't use h.264 couldn't share their screen reliably [389774, 39752].• Text could have appeared blurry when using Google Cast in the Chrome browser or Cast from a Chromebook or a mobile device [10784].
SMART Notebook Player for the display (education models only)	<ul style="list-style-type: none">• The Player app closed unexpectedly when a corrupted SMART Notebook file was opened [72942].• Customizations to the dice widget in a SMART Notebook file created on a computer wouldn't appear on the display [68883].• If more space was added to a page, the page contents might have become unreadable when the SMART Notebook file was exported as a PDF [64383].• When presenting a SMART Notebook file on the display, the ink in the SMART Notebook file might not been saved if the mobile device was no longer connected to a network [43205].
kapp Whiteboard	After erasing everything and adding new ink to a Whiteboard, a pinned Whiteboard tile showed the default icon instead of a thumbnail [46676].
Known issues	
System software	When copying a file that currently has the same file name as a file on a USB drive, the old file is not replaced on the USB drive. Rename the file on the display and then copy it to the USB drive [85347].
Screen Share	<ul style="list-style-type: none">• The Screen Share app on iPad with iOS 12.4.5 causes out-of-synch audio or no audio. Upgrade the iPad's operating system to the latest iOS version [90086].• Some devices may have trouble using Miracast to share the screen. Tap Restart Screen Share in the Screen Share lobby [72471].<ul style="list-style-type: none">◦ Tap Restart Screen Share in the Screen Share lobby.◦ Enable Miracast Connection Handling in Settings.• When both Ethernet and Wi-Fi are enabled on the display, the Screen Share app shows the connection information for the Wi-Fi connection [417977].• Samsung mobile devices should use the Google™ Home app to share content [417994, 10815].• Text may appear blurry when using Google Cast in the Chrome browser or Cast from a Chromebook or a mobile device [407403].• Devices that can't use h.264 cannot share their screen reliably [389774].
SMART Notebook Player for the display (education models only)	<ul style="list-style-type: none">• When you are signed in to your SMART account, you cannot control the SMART Notebook lesson from your iOS or Android device.

- The following SMART Notebook file content is not supported by SMART Notebook Player:
 - Flash® widgets
 - GeoGebra
 - Lesson Activity toolkit
 - 3D objects
 - SMART blocks
 - Concept mapping
- The Player app closes unexpectedly when you open a SMART Notebook file that contains SMART response® 2 question set that has more than 10 images in it [18287].

smarttech.com/support
smarttech.com/contactsupport

© 2017–2020 SMART Technologies ULC. All rights reserved. SMART Board, SMART Notebook, SMART amp, SMART kapp iQ, SMART kapp iQ Pro, SMART response, smarttech, the SMART logo and all SMART taglines are trademarks or registered trademarks of SMART Technologies ULC in the U.S. and/or other countries. Google, Google Play, Chrome, Chromebook and YouTube are trademarks of Google Inc. Apple, iPhone and iPad are trademarks of Apple Inc., registered in the U.S. and other countries. All other third-party product and company names may be trademarks of their respective owners. Contents are subject to change without notice. April 9, 2020.